

Custom Angle Corner Guard Protractor

1. Fold along the dotted line
2. Hold axis point of protractor at the point of the wall corner, ensuring that the 0° line is up against the wall.
3. Hold a ruler horizontally up against the other section of the wall and extend it to the protractor, tracing a line
4. This line indicated the required angle of your corner guard.

